

## Update Win11 device drivers

**- These instructions apply only to InnoBeamer X2/LX2 Revision 4 -**

### 1. Device is not recognized properly

The device does not appear in the device list of the VibroMatrix or VibroLine software and in the Windows Device Manager, the device is marked with a yellow exclamation mark..

### 2. Update Driver

The driver is updated by reinstalling the VibroMatrix software. **Before doing so, the InnoBeamer X2/LX2 must receive a firmware update via the old driver on a functional Win10 system:**

Download Links:

[IBXUpdater2\\_2\\_518\\_WinUSB\\_Rev4.exe](#) (For execution on a Windows 10 computer)

[VibroMatrix\\_Setup\\_1.9.0.7805.exe](#) \* (To run on a Win11 computer)

1. Download the files from the download folder.

#### **WIN10 Computer**

2. Connect the InnoBeamer X2/LX2 to a computer (Win10) on which VibroMatrix with a working WIN10 driver is installed.

Run the firmware update [IBXUpdater2\\_2\\_518\\_WinUSB\\_Rev4.exe](#) here.

#### **WIN11 Computer**

3. Close all VibroMatrix programs and run the program [VibroMatrix-Setup\\_1.9.0.7805.exe](#) \*.

\* Version 1.9.0.7805 or newer